Manual Feed For Dematrons


Requirements

DP5.306.039 or later (DP510.017 or later will have Manual feed setup in DPService)


Device Software versions required

Dematron Software 9.25 or later Feeder Module software FTM 7.6 or later

Once setup with Dairyplan Manual feed will work without PC or if PC fails (DMS21 Gateway has to be functional for manual feed as it links Dematrons(DPNet-B) to Dpnet feeder Modules (DPNet-A))



Manual Feed For Dematrons (Double Up parlour)




Note

If Animal feed from Dairyplan is being dispensed if you attempt Manual feed the manual feed will not dispended

Manual feed for animal can only be activated once Dairyplan ration has been dispensed

Up to 10 can be selected via keypad Each press increases display by 1 When 10 is reached the next press rolls display back to F00 which is ZERO feed

Manual Feed For Dematrons **Swingover**




Note

Up to 10 can be selected via keypad Each press increases display by 1 When 10 is reached the next press rolls display back to 00 which is ZERO feed

DPSetup Dematron settings

(setting entered into DPSetup manually)



Reserved Parameter 050/999/012 (this example = 31 Sort Key (side 1))


where **XX** is feed modules address for each side 1st side usually = 31 2nd side usually = 32

Swingover = 31

DPSetup Feed Module settings


(setting entered into DPSetup manually)

Feed Module address (1st side) in this example is address **31**



Number of pulses per push of key / button

In this example 300/040/950 = 2
If Push Key / Button three times
Dematron display shows 3
then 3 x 2 = 6
6 drops of feed



Remember to set for all feed modules!

DPSetup Feeding in a row (Batch Manual Feed)

(setting entered into DPSetup manually)

aditional settings required in Reserved parameter 300/040/980


Feeder Module software FTM 7.6 or later

Note


at present you can only have individual stall manual feed or Batch for whole side

When setup for Batch feed, when Keypad Buttons press instead of induvial stall getting fed the Complete side gets fed, any keypad on same side of parlour can be used to start the batch feed

All Feeder Modules on **side one** of parlour should have **31** entered in Reserved parameter **300/040/980**



All Feeder Modules on **side two** of parlour should have **32** entered in Reserved parameter **300/040/98**0



DPService parlour settings

Using DP Version 5.310.017 & later the setup is now more automated

Configuration Properties Milk Parlour

400/180/050 = Yes

This sets the values in Dematron's & feeder module

Properties		
Ailk parlor 1		
- General		
400/180/004 - Parlor Description		
400/180/009 - Parlor Type	Group Parlor	
400/180/011 - Gate Control	Manual Gate Control	
400/180/023 - Milk Control Unit Type	Dematron 70	
400/180/012 - SwingOver	Not active	
400/180/005 - Number parlor sides	2	
099/990/742 - Standby Module Present?	Yes	
400/180/020 - Feeding	Yes	
400/180/007 - Number of motors per stall	1	
400/180/050 - Manual feeding with Dematron	Yes	
400/180/051 - Manual feed drop in a row	No	
- Parlor ID		
400/180/021 - Parlor ID type	VC3 / VC4 ID	
999/990/054 - VC4/VC3 ID Mode	14: FGM; SBS Walk through (VC4/3	
- Additional settings		
999/990/053 - Distribute rinsing cycle times for milk control units	Yes	
999/991/308 - Stripping control	No Stripping Control	
999/991/309 - Cup disinfection	No	
400/180/019 - Kick Off	No	
- Cluster Functions		
050/105/010 - Cluster down after detach	No	

These Dematron setting now set automatically once manual feed is selected in Parlour Configuration

Setup Properties Milk Control

Service 050/999/012

This is feed modules address for each side

Swingover = 31

Double up parlour 1st side usually = 31 2nd side usually = 32

Properties Milk Control Units 1		
050/040/132 - Rapid Vent Only During Attach	No	
050/040/133 - Delay Time Rapid Vent (s)	0.0	
050/999/009 - Detach according to target milk amount	Attention before Milking	
- Service		
050/040/100 - Lower Milk unit for Wash (F1 Button)	No	
050/040/120 - Central switch to milk	No	
050/010/062 - Central switch to wash	No	
050/010/063 - Switch to Wash by Remote Start	No	
040/000/060 - Function of Select Button (S21, Dematron)	Selection	
040/000/070. Enter number of new group instead of animal number	Mo	
050/999/012 - Manual feeding with Dematron	31	
Display		

DPService Feed Module settings (DP Version 5.310.017 & later)

Parlor Feeder Module 3	
Barn No.: 1 Feeder Output: 1	
300/040/011 - Portion Weight [kg]	0.000
300/040/012 - Pause Times	2.0
300/040/013 - Delay Time First Feed Portion	10.0
Barn No.: 2 Feeder Output: 1	
300/040/021 - Portion Weight [kg]	0.000
300/040/022 - Pause Times	2.0
300/040/023 - Delay Time First Feed Portion	10.0
- Barn No.: 3 Feeder Output: 1	15
300/040/031 - Portion Weight [kg]	0.000
300/040/032 - Pause Times	2.0
300/040/033 - Delay Time First Feed Portion	10.0
- Barn No.: 4 Feeder Output: 1	
300/040/041 - Portion Weight [kg]	0.000
300/040/042 - Pause Times	2.0
300/040/043 - Delay Time First Feed Portion	10.0
- Barn No.: 5 Feeder Output: 1	
300/040/051 - Portion Weight [kg]	0.000
300/040/052 - Pause Times	2.0
300/040/053 - Delay Time First Feed Portion	10.0
- Barn No.: 6 Feeder Output: 1	
300/040/061 - Portion Weight [kg]	0.000
300/040/062 - Pause Times	2.0
300/040/063 - Delay Time First Feed Portion	10.0
Device Parameters (Configuration data)	
300/040/102 - Impulse duration special feed motors [sec]	0.0
300/040/103 - Basic feed ration [kg] (fed at first motor)	0.000
300/040/950 - Feed type 1: Number of feed portions per feed pulse	1
300/040/300 - Feed type 2. Number of feed portions per feed pulse	Ü
300/040/970 - Feed type 3: Number of feed portions per feed pulse	0
300/040/980 - Manual feed drop in a row	0
300/040/930 - Reserve-Parameter	100
300/040/940 - Reserve-Parameter	100
300/040/990 - Reserve-Parameter	100

Number of pulses per push of key / button

In this example 300/040/950 = 1
If Push Key / Button three times
Dematron display shows 3
then 3 x 1 = 3
3 drops of feed

Remember to set for all feed modules!

DPService Feeding in a row (Batch Row Manual Feed) (DP Version 5.310.017 & later)

Note

at present you can only have individual stall manual feed or Batch for whole side

When setup for Batch feed, when Keypad Buttons press instead of induvial stall getting fed the Complete side gets fed, any keypad on same side of parlour can be used to start the batch feed

Configuration Properties Milk Parlour

400/180/050 = Yes Manual Feed With Dematron 400/180/051 = Yes Manual Feed drop in row

This sets the values in Dematron's & feeder module

lk parlor 1	
General	
400/180/004 - Parlor Description	
400/180/009 - Parlor Type	Group Parlor
400/180/011 - Gate Control	Manual Gate Control
400/180/023 - Milk Control Unit Type	Dematron 70
400/180/012 - SwingOver	Not active
400/180/005 - Number parlor sides	2
099/990/742 - Standby Module Present?	Yes
400/180/020 - Feeding	Yes
400/180/007 - Number of motors per stall	1
400/180/050 - Manual feeding with Dematron	Yes
400/180/051 - Manual feed drop in a row	Yes
Parior ID	-
400/180/021 - Parlor ID type	VC3 / VC4 ID
999/990/054 - VC4/VC3 ID Mode	14: FGM; SBS Walk through (VC4/3
Additional settings	
999/990/053 - Distribute rinsing cycle times for milk control units	Yes
999/991/308 - Stripping control	No Stripping Control
999/991/309 - Cup disinfection	No
400/180/019 - Kick Off	No
Cluster Functions	